



Stringers sit on top of these formers

Stringers but up to this former

Outlines 1/16" balsa

Outlines 1/16" balsa

All formers 1/16" balsa

CG Range

3/32" sq.

.047 wire

Wrap landing gear wire with thread and glue well. Then add angle braces.

Do not attach here.

Typical stab & rudder cross-section